

TTP125-003 SERIES PDU

Technical Specifications

Input	Input Protections
1x CEE 125A 400V 5P (Mennekes)	1x Main MCCB 125A 4P I _{cn} :25kA (Siemens) with extended rotary handle 1x Voltage monitoring relay (VMR) (Schneider Electric)

Outputs	Outputs Protections
2x CEE 63A 400A 5P (Mennekes)	2x MCB C63A 4P and 2x RCCB 63A 300mA 4P Selective A-type (Siemens)
2x CEE 32A 400A 5P (Mennekes)	2x RCBO C32A 30mA 4P A-type (Siemens)
6x Auxiliary connector 230V 3P (Optional)	6x RCBO C16A* 30mA 1P A-type (Siemens)
1x HAN® GND grounding connector (Harting)	

*For selected auxiliary connectors, the rated current of RCBO varies. J1 version is with RCBO C10A 30mA 1P A-type; and G1 and B1 versions are with RCBO C13A 30mA 1P A-type.

Additional Functionalities

- **Remote Power Monitoring:** Integrated Siemens PAC3220 Power Monitoring Device with three current transformers for comprehensive real-time metering of voltage, current, power, and energy consumption. Remote access is enabled via two panel-mounted CAT5E (RJ45) connectors, supporting Modbus TCP/IP communication (45–65 Hz). Each device receives a unique IP address, allowing direct access through any web browser; no additional software required. Users can monitor system parameters live from computers, smartphones, or tablets on the same network, making it an ideal tool for proactive diagnostics, energy management, and grid optimization.
- **Voltage Monitoring Relay (VMR):** The system includes a phase-to-neutral Voltage Monitoring Relay (VMR), which continuously monitors voltage integrity. It detects and responds to critical anomalies such as phase loss, missing neutral, overvoltage, and undervoltage. Upon identifying a fault, the VMR can trigger a power disconnection or alarm to protect connected equipment and maintain system stability. This protection is essential for setups using sensitive electronics or operating under unstable power conditions.
- **VMR Bypass Key Switch:** A secure key-operated switch allows temporary bypass of the VMR for specific diagnostic or maintenance operations. This function is intended for use by qualified personnel and provides flexibility without compromising system safety.
- **Selective Residual Current Protection:** The unit includes selective RCCBs (Residual Current Circuit Breakers) on specific outputs to ensure fault isolation without triggering

upstream devices. Unlike standard RCCBs, selective types are designed with a deliberate time delay, allowing downstream protection devices (such as RCBOs) to respond to faults first. This coordination avoids unnecessary power loss across the entire system in the event of a local fault, ensuring greater continuity of service and enhanced operational safety; especially in complex, multi-distribution setups.

- **Emergency Stop (E-Stop):** A Schneider Electric emergency pushbutton is mounted on the front panel, enabling immediate shutdown of all outputs. Monitoring systems, diagnostic tools, and working lights remain operational via independently protected auxiliary circuits, facilitating post-trip fault identification and rapid intervention.
- **Integrated Work Lights:** Equipped with one front and one rear working light, controlled by front-panel pushbuttons. These lights improve safety and visibility during operation, setup, or maintenance in low-light environments such as backstage or industrial sites.
- **MCCB Operation with Shunt Trip Release:** The input-side MCCB is equipped with a shunt trip release mechanism, enabling remote disconnection of power under fault or emergency conditions. This feature allows the MCCB to be tripped via external signals (such as emergency stop systems, VMR alarms, or monitoring relays) enhancing safety and control across the power distribution chain.
- **Indicator LEDs**
 - 6x Phase presence indicator white LED (L1, L2, L3)
 - 3x MCCB "ON" state green LED
 - 1x MCCB "TRIP" state red LED
 - 2x RCBO "I-ON" state green LED for CEE 63A 5P output connectors
 - 2x RCBO "I-ON" state green LED for CEE 32A 5P output connectors
 - 6x RCBO "I-ON" state green LED for auxiliary connectors
 - 1x Fault Indicator red LED triggered by VMR
- **Independent fuses:** All monitoring, emergency, and lighting functions (such as the power monitoring device, VMR, and related indicator LEDs) are powered through independently fused circuits. In the event of an MCCB trip, these systems remain active to support fault identification and ensure continued diagnostic visibility.

Mechanical & Electrical Design

- **Ingress Protection:** IP54-rated enclosure, including transparent hinged covers for MCCB, RCBOs, and VMR components, providing dust protection and water splash resistance in semi-outdoor or protected outdoor environments.
- **Enclosure Material:** Constructed from high-density polyethylene (HDPE) with a structured surface. The material is UV-stabilized and water-resistant, ensuring long-term durability and mechanical strength in demanding field applications.
- **Overall Dimensions:** 605 x 525 x 555 in mm (Height × Width × Depth).
- **Handles:** Equipped with two heavy-duty industrial-grade handles for safe and ergonomic transport.

- **Feet:** Eight stainless steel stacking feet are installed for wear resistance and to support stable, vertical stacking during storage or transport. The stackable design allows for modular handling of identical units.
- **Labeling:** All connectors and protective devices are identified with UV-printed markings. UV printing ensures resistance to environmental degradation, including UV exposure and solvent-based cleaning agents.
- **Connector Installation:** Equipped with Quick Connector Replacement (QCR) system. Connectors are mounted with four stainless steel screws and sufficient internal cable slack to enable replacement without disassembling the entire enclosure.
- **Internal Conductor Cross-Sections:**
 - 125A circuits: 50 mm² (Cu)
 - 63A circuits: 16 mm² (Cu)
 - 32A circuits: 6 mm² (Cu)
 - 16A circuits: 2.5 mm² (Cu)
- **Wiring and Components:**
 - Internal cabling: Helukabel flexible conductors, H07V-K or equivalent.
 - Terminal blocks: Phoenix Contact or Ouneva spring-cage or screw-type terminals, selected per application and load class.

Electrical Specifications

- Rated voltage (U_n): 400 V AC, 3P+N+PE
- Rated current (I_{nA}): 125 A
- Frequency (f_n): 50/60 Hz
- Maximum continuous load: 86 kVA** (86 kW at $\cos\phi = 1$)
- Rated diversity factor (RDF): 0.56
- Rated conditional short-circuit current (I_{cc}): 25 kA (in accordance with EN 60898)
- Protection class: Class I (protective earth)

**At 30°C ambient air temperature

Environmental Ratings

- Operating temperature: -25 °C to +40 °C, with the average ambient temperature over a 24-hour period not exceeding 35 °C (in accordance with IEC/EN 61439 recommendations).
- Storage temperature: 0 °C to +40 °C
- Relative humidity: Maximum 100% at ambient temperatures from -25 °C to 27 °C, decreasing to 60% at 35 °C and 46% at 40 °C, non-condensing (in accordance with IEC/EN 61439 recommendations)
- Maximum installation altitude: ≤2000 m above sea level

Auxiliary Connector Options

The following configurations are available for auxiliary connectors:

Code	Type	Rated Current	IP Code***	Manufacturer
F1	German / Austrian (Type F)	16A	IP54	Mennekes
F2	German / Austrian with gasket (Type F)	16A	IP54	Mennekes
E1	French / Belgian (Type E)	16A	IP44	Mennekes
G1	British (Type G)	13A	IP44	ABL
P1	powerCON® TRUE1 with sealing self-closing cap	16A	IP65	Neutrik
J1	Swiss T13 (Type J)	10A	IP54	PCE
J2	Swiss T23 (Type J)	16A	IP54	PCE
B1	USA / Canada (Type B)	15A	IP44	ABL
K1	Danish (Type K)	16A	IP44	PCE
CE	CEE 6h	16A	IP54	Mennekes

***The stated IP rating applies when all enclosure lids and covers are fully closed. When connectors are mated, the overall ingress protection level may vary depending on the IP rating of the connected plugs. Users should ensure that all connected components maintain appropriate protection levels for the intended environment.

Ordering Information

The following table lists all standard configuration variants available for the TTP125-003 Series. Each part number corresponds to a specific auxiliary connector layout and color scheme.

Ordering Code	Connector Color Description		
	Input	CEE Outputs	Auxiliary Connector
TTP125-003-F1-B	Red	Black ^{PCE}	Black
TTP125-003-F1-C	Red	Red	Blue, Black, Grey
TTP125-003-F2-B	Red	Black ^{PCE}	Black
TTP125-003-F2-C	Red	Red	Blue, Black, Grey
TTP125-003-E1-B	Red	Black ^{PCE}	Black
TTP125-003-E1-C	Red	Red	Blue, Black, Grey
TTP125-003-G1-B	Red	Black ^{PCE}	Black
TTP125-003-G1-C	Red	Red	Black
TTP125-003-P1-B	Red	Black ^{PCE}	Black
TTP125-003-P1-C	Red	Red	Black
TTP125-003-J1-B	Red	Black ^{PCE}	Black with blue lid
TTP125-003-J1-C	Red	Red	Black with blue lid

Ordering Code	Connector Color Description		
	Input	CEE Outputs	Auxiliary Connector
TTP125-003-J2-B	Red	Black ^{PCE}	Black with blue lid
TTP125-003-J2-C	Red	Red	Black with blue lid
TTP125-003-B1-B	Red	Black ^{PCE}	Black
TTP125-003-B1-C	Red	Red	Black
TTP125-003-K1-B	Red	Black ^{PCE}	Black
TTP125-003-K1-C	Red	Red	Blue
TTP125-003-CE-B	Red	Black ^{PCE}	Black
TTP125-003-CE-C	Red	Red	Grey with blue lid

^{PCE} Where black-colored CEE connectors are not available from Mennekes, black variants from PCE are used to maintain a consistent appearance.

Connector Color Options:

- B = All connectors in black (where available).
- C = Color-coded connectors: red for input and grey/blue/black for outputs (where available), offering quick visual identification during setup.

Certifications & Standards

- **CE Compliance:** All components and final assemblies are CE certified, conforming to the requirements of applicable European directives, including the Low Voltage Directive (2014/35/EU) and the EMC Directive (2014/30/EU).
- **Standards Compliance:** Designed in accordance with the following international standards:
 - EN 61439-1: Low-voltage switchgear and controlgear assemblies – General rules.
 - EN 61439-4: Assemblies for construction sites (ACS).
- **Manufacturer Information:**
 Designed and manufactured by:
 Tesla Entertainment Kft.
 Address: H-1151 Budapest, Károlyi Sándor út 158.; Hungary
 EU VAT ID: HU26587255
- **Country of Origin:** Hungary; all units are assembled and tested at our facility in Budapest.

Safety Notice

- This device must be installed, operated, and maintained by qualified personnel only. Internal components may carry live voltage during operation. Maintenance tasks, including connector replacement, must only be carried out with the power supply fully disconnected/isolated.
- All safety guidelines, installation procedures, and maintenance instructions are provided in the product's user manual. Please read and follow them carefully to ensure safe and correct operation.

- For full warranty terms and legal information, please refer to our General Terms and Conditions available at: <https://TeslaTech.GmbH/GTCS>

Disclaimer & Copyright

- All specifications are subject to change without notice.
- This document, including its structure, layout, and contents, is the intellectual property of Tesla Entertainment Kft. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means without the prior written permission of the owner. Tesla Entertainment Kft. reserves all rights to the designs, technical data, and configurations presented herein.